

Digital Camera Fit Chart - Digital Series

	5688	5690	5691	5692	5693	5694	5696	5683	5685
<ul style="list-style-type: none"> • Total Coverage Tops • Dual Foam Technology™ • Universal Memory & Battery Pockets. • Constructed of Ballistic Nylon. • Metal Hardware 	<p>Sub-Compact Digital Camera Pouch Perfect for Elph or lrus-sized digital cameras & an extra memory card.</p>	<p>Compact Digital Camera Bag Holds compact digital cameras, memory cards and batteries.</p>	<p>Digital 1 Holds slim digital cameras, memory cards and batteries.</p>	<p>Digital 2 Perfect for smaller digital cameras, memory cards and batteries.</p>	<p>Digital 3 Ideal for square-shaped digital cameras, memory cards and batteries.</p>	<p>Digital 4 Carries most standard-sized digital cameras, memory cards and batteries.</p>	<p>Digital 6 Holds larger digital cameras, memory cards and batteries.</p>	<p>Digital Zoom Pack For cameras with large built-in zoom lenses.</p>	<p>Digital Double Decker For Cameras and Accessories.</p>
Digital Cameras									
CANON									
Powershot S200, S230, S400	X								
Powershot S330		X							
A60, A70, A100, A200, A300, S30, S40, S45, S50,			X						
Powershot A40				X					
Powershot G2					X				X with accessories
Powershot G3							X		X with accessories
CASIO									
Exilim EX-S2, EX-S3, EX-M2	X								
QV-R, EX-Z3		X							
QV4000, QV5700					X				
FUJI									
Finepix F700			X						
A101, A200, A201, A203, A303, F402, F410, F601, 30i				X					
2600, 2650					X				
1400, 2400						X			
S602, 2800, 3800								X	
HEWLETT PACKARD									
PS120, 318, 320, 735, 812, 935				X					
PS720, 620, C215, C315, 612					X				
PS850, 912							X		
KODAK									
LS420, LS633			X						
LS443, CX4200, CX4230, CX4300, DX3215, DX3700, DX3900, DX4330, DX4900, DX6340				X					
DX3500, DX3600					X				
KONICA									
Revio KD-300Z, KD-310Z, KD-400Z, KD-500Z		X							
KD-200Z			X						
e-mini M				X					
MINOLTA									
X, Xi, Xt		X							
F100, F200, F300			X						
DiMage E223				X					
DiMage S304, S404, S414					X				
DiMage 5, 7, 7i, 7Hi							X	X	

Digital Camera Fit Chart - Digital Series

	5688	5690	5691	5692	5693	5694	5696	5683	5685
<ul style="list-style-type: none"> • Total Coverage Tops • Dual Foam Technology™ • Universal Memory & Battery Pockets. • Constructed of Ballistic Nylon. • Metal Hardware 	<p>Sub-Compact Digital Camera Pouch Perfect for Elph or Ixus-sized digital cameras & an extra memory card.</p>	<p>Compact Digital Camera Bag Holds compact digital cameras, memory cards and batteries.</p>	<p>Digital 1 Holds slim digital cameras, memory cards and batteries.</p>	<p>Digital 2 Perfect for smaller digital cameras, memory cards and batteries.</p>	<p>Digital 3 Ideal for square-shaped digital cameras, memory cards and batteries.</p>	<p>Digital 4 Carries most standard-sized digital cameras, memory cards and batteries.</p>	<p>Digital 6 Holds larger digital cameras, memory cards and batteries.</p>	<p>Digital Zoom Pack For cameras with large built-in zoom lenses.</p>	<p>Digital Double Decker For Cameras and Accessories.</p>
Digital Cameras									
NIKON									
Coolpix 2100, 3100		X							
Coolpix 2500, 3500			X						
Coolpix 885, 2000, 4300, SQ				X					
Coolpix 4500						X			X with accessories
Coolpix 5000							X		X with accessories
Coolpix 5700								X	
OLYMPUS									
Stylus Digital 300, 400, D-390, D-560			X						
C-50 Zoom, D-40, D-380, D-520 Zoom, D-550 Zoom				X					
C-720 Ultra Zoom, C-730 Ultra Zoom, C-740, C-750, C-4000 Zoom, C-5050 Zoom							X	X	X with accessories
E-10, E-20N									X
PANASONIC									
SV-AV10	X								
DMC-F7			X						
DMC-LC20K, LC20S				X					
DMC-LC5K, LC5S, LC40K, LC40S					X				
PV-SD4090							X		
PENTAX									
Optio S, 330, 430, 330RS, 430RS		X							
Optio 450, 550			X						
Optio 230, 330GS, 33L				X					
SONY									
DSC-U10, 20	X								
Cybershot DSC-P7, P8, P10, P31, P32, P71, P72, P92			X						
Cybershot DSC-P3, P9, P20, P51, P52				X					
Cybershot DSC-S85, V1					X				
MVC-CD350, 500, FD200							X		
DCS-F717							X or Model 5697		X with accessories
TOSHIBA									
PDR-3310, T10		X							
PDR-T20, T30			X						
PDR-2300, 3300, 3320, T25				X					
YASHICA/KYOCERA									
Finecam S3, SRX, S4	X								
Finecam S3L, S5		X							
Finecam L3V, L4V			X						